

Spare parts for F-1600 mud pumps		
1	Cylinder with bolts	AH13010105001
2	180 Cylinder liner	AH000003031700
3	170 Cylinder liner	AH000003031600
4	160 Cylinder liner	AH000003031500
5	150 Cylinder liner	AH000003031400
6	180 Piston	AH0000040900
7	170 Piston	AH0000040800
8	160 Piston	AH0000040700
9	150 Piston	AH0000040600
10	180 Piston rubber	AH000004090200
11	170 Piston rubber	AH000004080200
12	160 Piston rubber	AH000004070200
13	150 Piston rubber	AH000004060200
14	Valve assembly	AH0000020300
15	Valve rubber	AH000002030103
16	Piston rod assembly	AH1301010516
17	Intermediate rod	AH1301010409
18	Pulsation damper air sac	AK7535010200
19	Shear valve	AH0000060100
20	Clamp	AH130101051900
21	Valve spring	AH00000101
22	Cylinder seal ring	AH1301010512
23	Pressure gauge	YK150-65MPa
24	Valve bonnet seal ring	AH1301010510
25	Cylinder lid seal ring	AH1301010508
26	Piston seal ring	AH1301010515
27	Upper baffle	AH1301010402
28	Lower baffle	AH1301010412
29	Crosshead	AH1301020401
30	Piston circlip	AH0000040404
31	Oil seal ring	AH1301010405
32	Piston nut	T507-305.00
33	Two-lip oil seal	AH1301010406
34	Shear pin(safety valve)	AH0000060111
35	Buffer(safety valve)	AH0000060106
36	Discharge strainer	AH1001021100
37	Breather cap	T515-101.00
38	Bearing carrier right	AH1601020101
39	Crankshaft	AH130102020400
40	Gasket main bearing cover	AH3010100203
41	Inner Race retainer	AH1301010204
42	Outer race retainer	AH160101010200
43	Eccentric strap	AH1601020102
44	Inner Race retainer (I)	AH10301020203
45	Inner Race retainer (II)	AH1301020205
46	Piston Nut 1 1/2-8UNX5 1/2	T501-303.0
47	Capscrew 1 1/2-8UNX5 1/2	T500-2023
48	Spacer main bearing	AH1301010211
49	Bearing carrier (LEFT)	AH1601020103